



EXTREME TACTICAL DYNAMICS

SERVING THOSE WHO SERVE US™

1410 Park Lane South Suite 4 - Jupiter, FL – 33458

Phone 888.893.3308 • Fax 561.427.0974 • Email customerservice@extremetacticaldynamics.com

80 Watt 4 Head Strobe Light Kit Wiring and Installation Guide

Extreme Tactical Dynamics 80-watt 4 head strobe tube kit is designed for interior installation. The safety and efficiency of this unit is dependent upon proper installation. **We highly recommend this strobe tube kit be installed by someone with a good working knowledge of automotive electronics, preferably an EVT.** It is important to read all of the information contained in this document before installing.



Strobe Tube Kit Installation Instructions

- Install power supply (must be in a safe, easy to reach location)
- Route cable from lights to power supply (don't let the cable chafe or bind at any point)
- No cables should be near hot engine spots
- All male terminals should be facing power supply, all female terminals should be near terminal
- Terminals should be inserted in Tyco connectors and on ends of all conductor cables
- Follow color code
- Connect cables to all 4 strobe light heads
- Connect cables to output sockets in power supply

How to Power 80-Watt Strobe Tube Kit

- Locate power input socket
- Plug three pin harness into input

- Ground kit
- Connect red wire to switch box

Keep instructions in a dry, safe place for reference during re-installation, maintenance, or repair. Improper use or installation of this strobe tube kit could void your manufacturer's warranty.