

1410 Park Lane South Suite 4 - Jupiter, Fl - 33458

Phone 888.893.3308 • Fax 561.427.0974 • Email customerservice@extremetacticaldynamics.com

LED Hideaway 9 Installation and Wiring Instructions


We recommend these <u>emergency lights</u> are installed by an EVT. EVTs are certified to install, repair, or maintain emergency vehicle equipment. Below, you will find instructions on how to install or repair these lights.

Important Installation and Wiring Information for LED Hideaway 9

- Do not cut the wire between the in-line flasher and lighthead
- Hideaways should only be used on approved vehicles
- Don't install or route wires near airbag deployment areas
- · Consult vehicle manufacturer's wiring diagram before proceeding with install or wiring to prevent damage



- 1. Remove taillight or headlight reflector assembly (follow vehicle manufacturer's instructions)
- 2. Choose a flat hideaway location with a 1" clearance that won't interfere with lamp operation The hideaway location you choose should be as close to the focal point as possible.
- 3. Drill a 1" hole in reflector housing with a hole saw
- 4. De-burr hole
- 5. Place hideaway in drilled hole
- 6. Mark mounting locations
- 7. Install light using included hardware (only use approved hardware)
- 8. Complete wiring (wiring instructions below)
- 9. Re-install light's reflector assembly





page: 1

